

IS - IMPERIAL HEXAGON AF SIZE HEAVY DUTY SOCKETS




Hi-Force high quality imperial size heavy duty sockets are designed and manufactured for use with all Hi-Force bolting products, including hydraulic torque wrenches and impact wrenches. The IS range of imperial impact sockets offers 47 models, with square drives from $\frac{3}{4}$ " to $2\frac{1}{2}$ " and across flat sizes up to $6\frac{7}{8}$ ". Long length, bi-hexagonal and special sockets are available on request.

Square drives from $\frac{3}{4}$ " to $2\frac{1}{2}$ "

Across flat sizes up to $6\frac{7}{8}$ "

Supplied complete with retaining ring and pin



Model number	Square drive	Nut AF inches	Dimensions in inches			
			A	B	C	D
IS2-101	$\frac{3}{4}$ "	$1\frac{1}{16}$ "	2.05	1.58	1.50	0.63
IS2-104	$\frac{3}{4}$ "	$1\frac{1}{4}$ "	2.05	1.73	1.73	0.79
IS2-107	$\frac{3}{4}$ "	$1\frac{7}{16}$ "	2.21	2.01	1.73	0.91
IS2-110	$\frac{3}{4}$ "	$1\frac{5}{8}$ "	2.44	2.29	1.73	1.06
IS2-113	$\frac{3}{4}$ "	$1\frac{13}{16}$ "	2.68	2.64	1.73	1.26
IS2-200	$\frac{3}{4}$ "	2"	2.84	2.80	2.13	1.38
IS2-203	$\frac{3}{4}$ "	$2\frac{3}{16}$ "	2.92	3.03	2.13	1.38
IS2-206	$\frac{3}{4}$ "	$2\frac{3}{8}$ "	2.96	3.31	2.13	1.38
IS9-101	1"	$1\frac{1}{16}$ "	2.29	1.73	2.01	0.67
IS9-104	1"	$1\frac{1}{4}$ "	2.36	2.01	2.01	0.83
IS9-107	1"	$1\frac{7}{16}$ "	2.44	2.21	2.05	1.02
IS9-110	1"	$1\frac{5}{8}$ "	2.44	2.44	2.05	1.02
IS9-113	1"	$1\frac{13}{16}$ "	2.52	2.68	2.29	1.06
IS9-200	1"	2"	2.76	2.92	2.29	1.22
IS9-203	1"	$2\frac{3}{16}$ "	2.84	3.15	2.44	1.26
IS9-206	1"	$2\frac{3}{8}$ "	3.07	3.43	2.44	1.38
IS9-209	1"	$2\frac{9}{16}$ "	3.15	3.66	2.44	1.42
IS9-212	1"	$2\frac{3}{4}$ "	3.35	3.86	2.44	1.58
IS9-215	1"	$2\frac{15}{16}$ "	3.74	4.10	3.39	1.89
IS9-302	1"	$3\frac{1}{8}$ "	3.94	4.29	3.39	2.05
IS9-308	1"	$3\frac{1}{2}$ "	4.14	4.93	3.39	2.05
IS9-314	1"	$3\frac{7}{8}$ "	4.14	5.36	3.74	2.05
IS5-113	$1\frac{1}{2}$ "	$1\frac{13}{16}$ "	3.31	3.00	3.39	1.06
IS5-200	$1\frac{1}{2}$ "	2"	3.43	3.23	3.39	1.14

Model number	Square drive	Nut AF inches	Dimensions in inches			
			A	B	C	D
IS5-203	$1\frac{1}{2}$ "	$2\frac{3}{16}$ "	3.55	3.39	3.39	1.42
IS5-206	$1\frac{1}{2}$ "	$2\frac{3}{8}$ "	3.62	3.66	3.39	1.50
IS5-209	$1\frac{1}{2}$ "	$2\frac{9}{16}$ "	3.74	3.82	3.39	1.58
IS5-212	$1\frac{1}{2}$ "	$2\frac{3}{4}$ "	3.94	4.14	3.39	1.69
IS5-215	$1\frac{1}{2}$ "	$2\frac{15}{16}$ "	4.06	4.33	3.39	1.77
IS5-302	$1\frac{1}{2}$ "	$3\frac{1}{8}$ "	4.33	4.57	3.39	1.97
IS5-308	$1\frac{1}{2}$ "	$3\frac{1}{2}$ "	4.65	5.12	3.39	2.17
IS5-314	$1\frac{1}{2}$ "	$3\frac{7}{8}$ "	4.93	5.52	3.74	2.29
IS5-404	$1\frac{1}{2}$ "	$4\frac{1}{4}$ "	4.93	5.91	3.74	2.29
IS5-410	$1\frac{1}{2}$ "	$4\frac{5}{8}$ "	5.32	6.50	3.74	2.56
IS5-500	$1\frac{1}{2}$ "	5"	5.52	7.05	5.00	2.76
IS5-506	$1\frac{1}{2}$ "	$5\frac{3}{8}$ "	5.91	7.68	5.00	2.96
IS6-302	$2\frac{1}{2}$ "	$3\frac{1}{8}$ "	5.52	4.89	5.00	2.01
IS6-308	$2\frac{1}{2}$ "	$3\frac{1}{2}$ "	5.52	5.32	5.00	2.01
IS6-314	$2\frac{1}{2}$ "	$3\frac{7}{8}$ "	5.91	5.79	5.00	2.25
IS6-404	$2\frac{1}{2}$ "	$4\frac{1}{4}$ "	6.30	6.26	5.00	2.52
IS6-410	$2\frac{1}{2}$ "	$4\frac{5}{8}$ "	6.70	6.78	5.00	2.80
IS6-500	$2\frac{1}{2}$ "	5"	6.90	7.29	5.00	2.96
IS6-506	$2\frac{1}{2}$ "	$5\frac{3}{8}$ "	7.09	7.76	5.00	3.11
IS6-512	$2\frac{1}{2}$ "	$5\frac{3}{4}$ "	7.29	8.27	5.00	3.27
IS6-602	$2\frac{1}{2}$ "	$6\frac{1}{8}$ "	7.49	8.79	5.00	3.59
IS6-608	$2\frac{1}{2}$ "	$6\frac{1}{2}$ "	7.68	9.26	5.00	3.74
IS6-614	$2\frac{1}{2}$ "	$6\frac{7}{8}$ "	7.88	9.77	5.00	4.14